

Paramount

Electric Fireplaces
Foyer Électrique

**OWNER'S MANUAL
(ENGLISH)**

ELECTRIC FIREPLACE

DBL-2000-MS



BEFORE OPERATING THIS EQUIPMENT PLEASE READ INSTRUCTIONS CAREFULLY.
FOR CUSTOMER SERVICE INQUIRIES, PLEASE CALL, 1-800-561-5550.

* Save this manual for future reference
Warning: Do not move stove while operating

TABLE OF CONTENTS

<i>SECTION 1: QUICK REFERENCE GUIDE</i>	2
<i>SECTION 2: WARNINGS & PRECAUTIONS</i>	
2.1 <i>Important Safety Instructions</i>	3
2.2 <i>Specifications</i>	4
2.3 <i>Testing The Unit</i>	5
<i>SECTION 3: OPERATING INSTRUCTIONS</i>	
3.1 <i>Grounding Instructions</i>	6
3.2 <i>Operation From The Control Panel</i>	6
3.3 <i>Operation By Remote Control</i>	7
<i>SECTION 4: MAINTENANCE</i>	
4.1 <i>Light Bulb Replacement Procedure</i>	9
4.2 <i>Tools Required</i>	10
4.3 <i>Removing The Top Of The Unit</i>	10
4.4 <i>Replacing The Top Contrasting Light Bulb</i>	11
4.5 <i>Replacing The Log Set Ember Bed Light Bulbs</i>	11
4.6 <i>Replacing The Flame Generation Light Bulbs</i>	12
4.7 <i>Cleaning The Front Glass Panel</i>	13
<i>SECTION 5: WARRANTY</i>	14



CAUTION: BEFORE OPERATING THIS EQUIPMENT PLEASE READ THESE INSTRUCTIONS CAREFULLY

SECTION 1

QUICK REFERENCE GUIDE

1. Before permanently placing your fireplace, plug it into a convenient outlet to verify that the circuit breakers for the outlet are on.
2. The electric fireplace may emit a slight, harmless odor when first used. This odor is normal and it is caused by the initial heating of internal fireplace parts and will not occur again.
3. If your electrical fireplace does not emit heat, consult your Owner's Manual for further information.
4. Use with a CSA or UL certified surge protector.



SA1965

CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN
NO USER - SERVICEABLE PARTS INSIDE
HIGH TEMPERATURE



SA1965

CAUTION: High temperature, risk of fire, keep electrical cords, drapery, furnishings, and other combustibles at least 3 feet (0.9m) from the front of the heater and away from the side and rear.

WARNING:

1. RISK OF FIRE - KEEP COMBUSTIBLE MATERIAL AWAY FROM THE FRONT OF THE ELECTRICAL FIREPLACE.
2. SERVICING SHOULD BE DONE ONLY WHILE THE ELECTRICAL FIREPLACE IS DISCONNECTED FROM THE POWER SUPPLY CIRCUIT.

REPLACEMENT LIGHT BULB CAUTION:

FOR LOWER LIGHT BULBS (LOG SET EMBER BED) AND FLAME GENERATION LIGHT BULBS, REPLACEMENT SHOULD ONLY BE WITH TYPE GX6.35 LIGHT BULBS, RATED 120V, 35W MAXIMUM. FOR UPPER LIGHT BULBS (TOP CONTRASTING LIGHT BULB), REPLACEMENT SHOULD ONLY BE WITH TYPE GX6.35 LIGHT BULB, RATED 120V, 35W.

SECTION 2

WARNINGS & PRECAUTIONS

2.1 IMPORTANT SAFETY INSTRUCTIONS



This symbol alerts you to potential hazards that can kill or hurt you and others.



DANGER



WARNING

You can be killed or seriously injured if you don't immediately follow instructions

All safety messages will tell you what the potential hazard is, tell you how to reduce the chance of injury, and tell you what can happen if the instructions are not followed.

IMPORTANT INSTRUCTIONS



Warning: When using this product, basic precautions should always be followed, including the following:

When using electric appliances; basic precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

1. Read all instructions before using this heater.
2. This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. If provided, use handles when moving this heater. Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 meters) from the front of the heater and keep them away from the sides and rear.
3. Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
4. Always unplug heater when not in use.
5. Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner. Return heater to authorized service facility for examination, electrical or mechanical adjustment, or repair.
6. Do not use outdoors.
7. This heater is not intended for use in bathrooms, laundry areas and similar indoor locations. Never locate heater where it may fall into a bathtub or other water container.

SECTION 2

WARNINGS & PRECAUTIONS

2.1 IMPORTANT SAFETY INSTRUCTIONS CONT'D

8. Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or the like. Arrange cord away from traffic area and where it will not be tipped over.
9. To disconnect heater, turn controls to off, then remove plug from outlet.
10. Connect to properly grounded outlets only.
11. Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
12. To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
13. A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.
14. Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
15. Avoid the use of an extension cord because the extension cord may overheat and cause a risk of fire. However, if you have to use an extension cord, the cord shall be No. 14 AWG minimum size and rated not less than 1875 watts.
16. **SAVE THESE INSTRUCTIONS**

2.2 SPECIFICATIONS

MODEL	DBL-2000-MS
POWER SUPPLY	120VAC; 15A Grounded Circuit
FREQUENCY	60Hz
HEATER POWER	1500W
UNIT DIMENSIONS	29.53" W x 15.83" D x 26.57" H 75.0 cm W x 40.2 cm D x 67.5 cm H
NET WEIGHT	63.93 lbs/29.00kg

Note:

A dedicated power circuit is recommended for the unit but not required. Additional electrical appliances on the same circuit may exceed the current (amperage) rating for that circuit. If after the installation of your unit, the circuit breaker trips or the fuse fails on a repeated basis, then a dedicated circuit will likely be required.

Any new wiring must be done in compliance with local and national codes and other applicable regulations in order to reduce the risk of fire, electric shock or other injuries. It is strongly recommended that you hire a licensed electrician to complete any such work.

SECTION 2

WARNINGS & PRECAUTIONS

2.3 TESTING THE UNIT

Carefully remove the unit from the box. Prior to permanently installing the unit, test to make sure the unit operates properly by plugging the unit's power cord into a conveniently located 120V grounded outlet. Use a CSA or UL certified surge protector.



Caution: The unit's power cord must be connected to a properly grounded and protected 120V outlet. Always use ground fault protection where required by the electrical code.



Warning: Do not operate the unit if it is damaged or has malfunctioned. If you suspect the unit is damaged, please call customer service at 1-800-561-5550 before returning this unit to the store.

Refer to the Operating Instructions regarding the various controls and features of the unit.